# National Grid UK Electricity Transmission plc

# **NATIONAL SAFETY INSTRUCTION 31**

# CONTROL OF NATIONAL GRID ELECTRICITY TRANSMISSION SAFETY RULES & SUPPORTING DOCUMENTATION



Copyright National Grid plc 2020 ©, all rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means electronic, mechanical, photocopying, recording or otherwise, without the written permission of National Grid obtained from the issuing location.

The contents of National Grid documents are based on the needs of National Grid and the conditions under which it operates. It shall not therefore be assumed that the contents stated therein necessarily meet the particular circumstances and requirements of other organisations. The principles set out in this document are for information only and therefore National Grid is not liable to any third party for any loss or damage resulting from reliance on the contents. It is the responsibility of such external organisations to check that the document is the latest version and is appropriate for their purposes.

© National Grid plc 2020 – All Rights Reserved Uncontrolled when printed

### DOCUMENT HISTORY

| Issue | Date       | Summary of Changes /<br>Reason  | Author(s)                                     | Approved By (Title)                           |
|-------|------------|---|---|---|
| 1     | April 2014 | Renamed as "National<br>Safety Instruction and<br>Guidance" which now<br>incorporates and<br>replaces NSI 31 Issue 2. | NSI Review Group                              | ETAM Operations<br>North Manager Mike<br>Dean |
| 2     | Nov 2020   | Reformatted and minor<br>updates. Document is<br>now combined with NSI<br>32 which has now been<br>archived           | Electricity Transmission<br>Safety Rules Team | Head of ET<br>Operations<br>Matt Staley       |

#### **KEY CHANGES**

| Section | Amendments   |
|---------|--|
| General | NSI 32 and Guidance – 'Register of Approved Procedures for the Use on the Electricity Transmission System' - Issue 1 has now been combined with this document. |
| 3.1     | Removal of Live Line Working Specialised Procedures reference, and update of Management procedure that controls <b>Approved</b> documentation.                 |

## CONTENTS

|   |                   | Page |
|---|-------------------|------|
| 1 | Purpose and Scope | 1    |
| 2 | Definitions       | 1    |
| 3 | Procedure         | 1    |

### 1 Purpose and Scope

This procedure stipulates the requirements to control specific **Approved** procedures for use on the National Grid Electricity Transmission System. The National Grid Electricity Safety Rules make reference to specific **Approved** procedures for controlling high risk activities and the process for initiating, approving and withdrawing these procedures is outlined in this document.

### 2 Definitions

Terms printed in bold type are as defined in the Safety Rules.

#### 3 Procedure

- 3.1 The National Grid Electricity Transmission Safety Rules makes reference to **Approved** procedures for the following activities:
  - National Safety Instructions (NSIs)
  - Restoration of Motive Power (ROMP) Procedures
  - Sanction for Work (SFW) Procedures
  - G3 Procedures
  - G4 Procedures

These procedures will be managed, and a register maintained, by the Electricity Transmission Safety Rules Team. The process will be controlled by the application of Management Procedure AMBP 228 - Management and Communication of ET Operations.